

Conversion Factors

Area

Multiply	by	to obtain
Square millimeters	1.6E-03	Square inches
	1.0E-05	Square meters
	1.0E-02	square centimeters
	1.3E+00	Circular millimeters
Square centimeters	1.2E-04	Square yards
	1.1E-03	Square feet
	0.155	Square inches
	1.00E-04	Square meters
	100	Square millimeters
Square kilometers	0.3861	Square miles (US)
	1.20E+06	Square yards
	1.08E+07	Square feet
	1.00E+06	Square meters
	247.1	Acres (US)
Square inches (US)	0.00694	Square feet
	0.00077	Square yards
	6.45E-04	Square meters
	6.4516	Square centimeters
Square feet (US)	3.59E-08	Square miles (US)
	0.111111	Square yards
	144	Square inches
	0.0929	Square meters
	929.03	Square centimeters
	2.30E-05	Acres (US)
Square miles	640	Acres (US)
	3.10E+06	Square yards
	2.79E+07	Square feet
	2.59	Square kilometers
	2.59E+08	Square meters